

July 2019

FABRIC CARE AND MAINTENANCE

Applies to the following Innova products:

Melana, Nevada, Seaking, Spa Master, Terrain, Tropica, Pacifica (Standard and Textures - Hide, Weave and Dimple), Supra, Supelle, Terranova, Terranova Neo, Terranova Synthetic Leather and all Medical grade products.

Instructions:

All PVC and PU Synthetic Leather fabrics require a degree of maintenance and care. A regular, minimum weekly cleaning regimen with appropriate products will prolong the life of the upholstery.

Innova recommends the following cleaning procedure:

- Remove any loose dirt or soiling with a suitable cloth (e.g. microfibre) or soft bristled brush and lukewarm water.
- Apply a mild, lukewarm pH neutral soap solution with a sponge or soft bristled brush.
- Allow the soap to stand briefly, but not to dry.
- Remove soap residue with microfibre cloth and clean water.
- Dry thoroughly with dry microfibre cloth.

Do not use abrasive cleaners, steel wool or cleaners containing solvents, gasoline, petroleum distillates, plasticisers or concentrated bleach. These have the potential to damage the fabric surface and void the guarantee.

Healthcare Applications:

For sanitisation in a healthcare application Innova recommends the following procedure:

- Remove any loose dirt or soiling with a soft bristled brush and/or lukewarm water.
- Apply a solution of 10% bleach and 90% water with a clean white cloth.
- Rub gently and rinse with water dampened cloth to remove bleach concentrate.
- Frequency of cleaning to be no greater than once a week.